Camvest - Camera Mount Harness (FLCM-CMVT-01)



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Flycam DSLR Camvest



Telescopic Arm



1/4" Camera Bolt



BS100 1/4" to 3/8"

PART LIST


Camera Platform
Front Chest Plate
Arm
Main Hinge
Main Telescopic Pole

Camvest **Setup**

- Put on the Camvest comfortably over your shoulders.
- Fasten all buckles securely to hold the vest in place.





- Adjust the shoulder, chest, and side straps to achieve a snug and balanced fit.

Note: The Camvest features fully adjustable straps that can be tightened or loosened for maximum comfort during use.



Telescopic Arm Assembly

- Loosen and remove the first knob from the Telescopic Arm.





- Similarly, remove the second knob from the Telescopic Arm.





- Loosen the center knob from the Telescopic Arm and adjust the rod.






- Attach the Telescopic Arm to the Camvest and tighten the knobs to secure it.




Feature: The 3ft telescopic pole and 180° tilting ball head let you capture multi-dimensional shots.




- Loosen the front knob to enable further extension and positioning.
- Install the Quick Release Plate bolt (1/4" camera bolt).




- Tighten the Quick Release Plate nut using a screwdriver (Not Included).
- Attach the Quick Release Plate to the ball head.




- Tighten the Quick Release Plate to the ball head using a 3/16” Allen key.
- Attach the Quick Release Plate to the camera.




- Attach the Quick Release Plate to the camera and tighten the BS100 nut using a Screwdriver (Not Included).
- Adjust the camera angle as required.
- Lock the position by tightening the knob securely.






- Your Camvest is now fully assembled.

Note: The camera (Not Included) can face forward for POV shots or back towards you for third-person shots.





YOUR PROAIM CAMVEST - CAMERA MOUNT HARNESS
ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please contact us immediately and we promise our utmost support and care until you use our product.